

# Connecting and Calibrating a Load Cell with V-Link®

## V-Link® and Futek LSB300 Load Cell (Applies to V-Link®, SG-Link®, SG-Link® OEM, HS-Link®)

### Overview

MicroStrain's V-Link® Wireless Voltage Node has 4 differential input channels (strain channels) designed to support strain gauges, load cells, etc.



Futek's [LSB300 Series](#) is an S Beam Load Cell designed for use in platforms, silos and scales; for purposes of this discussion, we are using the 200 lbs capacity, full bridge model [FSH02077](#).

This technical note presents a step-by-step approach to connecting the load cell to the V-Link®, calibrating the load cell, and operating the system. It is assumed that the user is familiar with MicroStrain's V-Link® and Node Commander® software as well as load cell operation.


### Wiring Connection

The Futek load cell presents a 5 foot, polyurethane sheathed, shielded, connection [cable](#) with 6 flying leads. [Table 1](#) describes the individual leads' purpose and nomenclature:

1	Red	+EXC	+Excitation
2	Black	-EXC	-Excitation
3	Green	+SIG	+Signal
4	White	-SIG	-Signal
5	Orange	+SEN	+Sense
6	Blue	-SEN	-Sense
Shield	Silver	Grounded	Shield

**Table 1**

- To connect to the V-Link®, we need only deal with the Red, Black, Green, and White leads.
- Cut back the Orange and Blue leads and secure them to prevent shorting.
- Strip back each of the 4 remaining leads approximately ½”.
- Tin (with solder) each of the 4 leads to insure a good grip in the V-Link®'s terminal block connector.
- It is also strongly recommended that you solder the shielding of the cable to the Black lead as shown in [Picture 1](#). This will reduce noise in the system.




**Picture 1**

- Connect the 4 leads of the load cell to the V-Link<sup>®</sup> as shown in **Table 2** and **Picture 2**.
- For this example we are connecting to differential input channel 1 of the V-Link<sup>®</sup>.

Lead Color Code	Lead Function	V-Link Function	V-Link Pin
Red	+Excitation	Sensor Power Out	16
Black	-Excitation	Ground	17
Green	+Signal	Sensor 1-	15
White	-Signal	Sensor 1+	13

**Table 2**




**Picture 2**

### **Node Commander<sup>®</sup> software**

- Power-up the V-Link<sup>®</sup> and launch Node Commander<sup>®</sup> software.
- Establish communication with the V-Link<sup>®</sup> as normal.
- Proceed to the Configuration screen and enable the channel to which you connected the load cell (channel 1 in this case).
- Continue to the Channel 1 Configuration screen.

- Select the Midscale bullet under the Auto-Balance button.
- Click the Auto-Balance button.
- A pop-up window will appear similar to the example shown in [Picture 3](#).




**Picture 3**

The key information within the window is the 2040 bits and the 513 offset. We are looking for a value of approximately 2048 (+/- 50) bits. This is “mid-scale” on the V-Link<sup>®</sup>'s 0 – 4096 bit measurement range. Low-scale balancing will yield approximately 1024 bits; high-scale will be approximately 3072 bits. You should use mid-scale balancing if you are expecting equal amounts of positive and negative output from the load cell. Low-scale is used if you are expecting more positive and high-scale if more negative data.

The offset is used to get the measurement range to align with the expected load cell output. The value for mid-scale should be approximately 512 (+/- 10) for a balanced bridge situation. If these numbers are off, the wiring of the load cell to the V-Link<sup>®</sup> is likely not sound. Correct the wiring and re-run the auto-balancing to verify.

- Click OK to close the pop-up window.
- Click OK to close the Channel 1 Configuration screen.
- Click Apply and click OK to close the Configuration screen and return to main screen of Node Commander.
- Stream the node and exercise the load cell by hand to check you are getting proper output as shown in [Picture 4](#).



**Picture 4**

- If the data is opposite to what you would expect, i.e., it goes negative when you were expecting positive, switch the Green and White leads to the V-Link<sup>®</sup>.
- Now re-run the auto-balance procedure and stream to verify proper operation.

### Calibrations

We actually have several options to calibrate the load cell with the V-Link<sup>®</sup>:

- The “poor man calibration” – Hang several weights off the load cell and read the output of the V-Link<sup>®</sup>. A limiting factor for this option is the number and accuracy of the weights available.
- Use the factory calibration of the load cell. Futek calibrates the load cell and provides a sensitivity coefficient that allows us to calculate a slope and offset. A limiting factor for this option is that the factory calibration does not take into account the load cell connections to the V-Link<sup>®</sup> or the V-Link<sup>®</sup> electronics.
- Utilize a calibrated tensometer to apply at least ten loads over the entire range of the load cell. Not everyone has a large expensive testing apparatus, but this will give the most accurate results.

### Poor man calibration


- Securely hang the load cell to a sturdy structure that will support the weights you apply to the load cell, as shown in [Picture 5](#).



**Picture 5**


- Launch Node Commander<sup>®</sup> software.
- Establish communication with the V-Link<sup>®</sup> as normal.
- Proceed to the Configuration screen.
- Continue to the Channel 1 Configuration screen.
- Select A/D Value under Class and Bits under Units in the Conversion Class frame as shown in [Picture 6](#).

- Click OK to close the Channel 1 Configuration screen.




**Picture 6**

- Proceed by streaming the node and observing the bit output using various weights. In our example shown in [Picture 7](#), we are demonstrating four weights, i.e., 0 (no weight), 5 lbs, 10 lbs and 25 lbs.
- After making weight measurements, calculate a slope from the data using the formula  $y=mx+b$ . Please see our technical note for a step-by-step using Microsoft Excel.



**Picture 7**

- In our example we see a slope of 0.1389 and an offset of -282.55.
- Return to the Channel 1 Configuration screen.
- Select Force under Class and Lbf under Units in the Conversion Class frame as shown in [Picture 8](#).
- Click the Modify button and enter 0.1389 in Slope and -282.55 in Offset.
- Click Lock to apply the Slope and Offset.
- Click OK to close the Channel 1 Configuration screen.



**Picture 8**

- Proceed to again stream the node with no weight on the load cell.
- Observe the value in the stream graph.
- If the stream is not at zero, return to the Channel 1 Configuration screen.
- Modify the Offset by increasing or decreasing the value to zero the output.
- Hang different weights on the load cell to verify calibration throughout its range.

### Using Factory Calibration of Load Cell

- The load cell in this example has been calibrated at the factory in the tension direction.
- It has a calibration sheet indicating an output sensitivity of 1.7777 mV/V @ 200 Lbs.
- With this information we can calculate the slope as follows:
  - $1.7777 \text{ mV/V} \times 3 \text{ V (excitation voltage)} = 5.3331 \text{ mV}$  for full range of 200 Lbs
  - $5.3331 \text{ mV} \times 210 \text{ (user selectable gain)} = 1.119951 \text{ V}$
  - $1.119951 \text{ V} \times (3 \text{ V}/4096 \text{ Bits})$  (see note) = 1529.106432 Bits
  - $200 \text{ Lbs} / 1529.106432 \text{ Bits} = 0.130795$  (slope)
- Note: The V-Link<sup>®</sup> has a 12-bit A/D converter with a 3 volt excitation, resulting in 4096 Bits / 3 Volts = 0.000732 Bits/Volt.
- Return to the Channel 1 Configuration screen.
- Select Force under Class and Lbf under Units in the Conversion Class frame.
- Click the Modify button and enter 0.130795 in Slope and 0 in Offset.
- Click Lock to apply the Slope and Offset.
- Click OK to close the Channel 1 Configuration screen.
- Stream the node with no weight on the load cell.
- Observe the value in the stream graph.
- If the stream is not at zero, return to the Channel 1 Configuration screen.
- Modify the Offset by increasing or decreasing the value to zero the output.
- Hang different weights on the load cell to verify calibration throughout its range.


### Using a Calibrated Tensometer

- The procedure is very similar to the “poor man calibration”. Instead of hanging weights from the load cell, we are mounting the load cell into the tensometer as shown in [Picture 9](#), applying precision loads, and noting the corresponding bit values.



**Picture 9**

- Proceed by streaming the node and observing the bit output using various weights. In our example shown in [Picture 10](#), we are demonstrating 11 loads, i.e., 0 (no load), 21 lbs, 39 lbs, and so forth.
- After making weight measurements, calculate a slope from the data using the formula  $y=mx+b$ . Please see our technical note for a step-by-step using Microsoft Excel.



**Picture 10**

- In our example we see a slope of 0.1378 and an offset of -280.64.
- Return to the Channel 1 Configuration screen.
- Select Force under Class and Lbf under Units in the Conversion Class frame.
- Click the Modify button and enter 0.1378 in Slope and -280.64 in Offset.
- Click Lock to apply the Slope and Offset.
- Click OK to close the Channel 1 Configuration screen.
- Proceed to again stream the node with no load on the load cell.
- Observe the value in the stream graph.
- If the stream is not at zero, return to the Channel 1 Configuration screen.
- Modify the Offset by increasing or decreasing the value to zero the output.
- Apply different loads on the load cell to verify calibration throughout its range.
- Note: You should apply at least ten loads (even more is better) over the entire range of the load cell rating to increase the accuracy of the calibration.

### Support

MicroStrain support engineers are always available to expand on this subject and support you in any way we can.

